

Intercom

VoIP phones provide an intercom feature that allows you to instantly connect to other phones within your office. Intercom functionality is ideal for announcing visitors or asking a quick question.

When one phone intercoms another extension, it does not ring the other phone. Instead, the other phone will beep, and then its microphone and speaker turn on.

> To intercom

1. Dial 99{ext}. For example, to intercom extension 100, dial 99100. Or dial 99 and press the Extension BLF

On Phones that have BLF (Where you can see if someone's phone is on a call or busy with red light next to their name), you can simply dial 99 then press the button for who you want to intercom with.

Revision #4

Created 25 July 2024 00:41:08 by Daniel O

Updated 5 June 2025 16:14:38 by Daniel O