

Rebooting a Grandstream GXP2170

This guide shows two easy ways to reboot your GXP2170: from the phone's menu, or by power-cycling it. Use either method, both do the same thing.

Before you start


- **Finish any active calls.** Rebooting will disconnect calls.
 - Rebooting **does not erase settings** or voicemails. It just restarts the phone.
 - If you use a **wired headset** or **sidecar (EXT)**, leave them plugged in.
-

Method A: Reboot from the phone's menu (preferred)

1. Press the **Menu** key (the center round button).



2. Select **Reboot**. (you may use arrows or just press the number # 8 on dial pad)



3. When Highlighted press the **Menu key** (the center round button) to select it.
 4. When asked to confirm, choose **Yes**.
 5. The screen will go dark and the phone will restart. *(it may appear as its not doing anything, but give it about 15 seconds)*
-

Method B: Power-cycle the phone (unplug/replug)

If your phone uses **Power over Ethernet (PoE)**

1. Trace the **network cable** from the back of the phone to the wall jack or switch.
2. Unplug that **network cable** from the **back of the phone**.
3. Wait 10-15 seconds.
4. Plug the **same cable** back into the **LAN** port on the phone (not the PC pass-through port).

If your phone uses a **power adapter (wall power)**

1. Unplug the **round power plug** from the back of the phone **or** unplug the power brick from the wall.
 2. Wait 10-15 seconds.
 3. Plug it back in firmly to the phone and power outlet.
-

After the reboot

- The screen will show the Grandstream logo, then your extension.

- Line keys will light as the phone finishes registering.
 - You can place/receive calls once the line keys are solid and your name/extension is shown.
-

If the phone doesn't come back up

- Check the **network cable** is in the **LAN** port (not "PC").
 - For power adapter: verify the **power brick** is firmly connected at both ends and the outlet has power.
 - Look for on-screen messages like "**Not Registered**"; if you see this, note it for support.
-

When to contact IT/Support

- The phone shows "**Not Registered**" or can't make/receive calls after reboot.
- You see repeated reboots or error messages.
- Your **sidecar (EXT)** or **headset** doesn't power back on.

Provide your **extension number**, whether you used **PoE or power adapter**, and what you saw on the screen after the reboot.

Revision #5

Created 10 November 2025 16:59:03 by Daniel O

Updated 10 November 2025 17:09:30 by Daniel O